




Field test of the aerosol particle combined analyzer

- A new PM2.5 analyzer-

February 4, 2015 Fuji Electric Co., Ltd.


About Fuji Electric





Fuji Electric's sensors







About PM2.5





- **PM2.5** has various origins, sizes and chemical compositions (Fig.1, Fig.2)
- There are growing concerns about Health effects (Fig.3) and meteorological effects (Fig.4).
- **Reducing PM2.5 requests more detailed information (sizes, origins...).**





■ Aerosol Particle Size distribution (Fig.2)





Aerosol particle combined analyzer



Hourly mass concentration monitoring only

Particle size, number and composition real-time (every 15min) analysis. Possible applications: Inferring PM2.5 origins, Improving PM2.5 forecast

Existing method

■PM2.5 monitor

Mass concentration monitoring only, Composition analysis is impossible.






PM2.5 manual analysis
8-12 hours per analysis
Real-time measurement is impossible.



Fuji Electric's aerosol particle combined analyzer



This research was supported by Japan Science and Technology agency (2008~2012). The member of the joint research are The University of Tokyo, Japan Agency for Marine-Earth Science and Technology and Fuji Electric Co., Ltd.

Field test at Kawasaki city



Joint study between Kawasaki city and Fuji Electric (since 2013)

Kawasaki city





Takatsu general station





Manual analysis

PM2.5 monitoring


[Resources]

- PM2.5 monitoring data
- PM2.5 manual analysis data
- Weather data
- Air pollutant data



Aerosol combined analyzer (prototype)

Fuji Electric



Field observation


[Resources]

- PM2.5 mass concentration data
- PM2.5 real-time analysis data (particle chemical composition, size and number)




Example – Field test at Kawasaki general station






Intercomparison







Intercomparison between results of PM2.5 monitor and results of aerosol particle combined analyzer (daily data).

Trends show good correlation (approximately ± 20%)


Data analysis1—Nitrate vs NOx



- There is a correlation between nitrate and NOx gas.
- NOx gas rapidly changes into nitrate.



The origin of nitrate could be around here.



Data analysis2—Nitrate vs black carbon



Measurement results of nitrate


- There is a correlation between nitrate and NOx gas.
- NOx gas rapidly changes into nitrate.

Measurement results of black carbon

• There is a correlation between nitrate and black carbon.



The origin of nitrate could be automobiles around here.



Aerosol particle combined analyzer can provide PM2.5 origin information.

Joint study 2014


Verification of long term stability



Long term field measurement (more than 3 months)

- Studying PM2.5 component dynamics Peculiar case analysis, macro trend ...
- Developing the analyzer for commercialization Improving reliability, maintenance methods ...





We will contribute to reduce PM2.5.

空気の、テイスティング。



それぞれどんな成分がふくまれているのか、空気中のPM2.5の特性をリアルタイム分析。微小粒子の生まれた場所と原因の特定に、道を拓きます。

PM2.5発生源特定を可能にする

富士電機のエアロゾル複合分析技術

【第27回独創性を拓く先端技術大賞】企業・産学部門 特別賞受賞